



NanoBeam[®] Window Mount

Model: NBE-16-WM, NBE-19-WM

QUICK START GUIDE

Mount Compatibility

Mount	Compatible NanoBeam® Models
NBE-16-WM	NBE-5AC-16, NBE-M5-16
NBE-19-WM	NBE-2AC-13, NBE-M2-13, NBE-5AC-19, NBE-M5-19

Package Contents



Suction Cup Mount



NBE-16-WM
Ball Joint Mount
Attachment

or



NBE-19-WM
Ball Joint Mount
Attachment

Installation

1. Connect the *Ball Joint Mount Attachment* to the mount arm of the *Suction Cup Mount*.



2. Attach the Ball Joint Mount and the Locking Nut from the NanoBeam to the *Ball Joint Mount Attachment*.



3. Attach the NanoBeam.



4. Place the NanoBeam Window Mount on the window. Turn the *Suction Lock* clockwise to secure it in place.

