

# WHO WE ARE

Stromberg Carlson was founded by Alfred Stromberg and Androv Carlson in 1894, in Chicago, USA. They quickly established a reputation for creating durable products of high technological quality. Continuing this legacy of over a century is our mission.

# CARE



When the battery runs out, charge for at least 30 minutes before using again.

Charge for 4 hours for a full charge.


Don't keep it plugged in all the time!



Do not get wet



Do not hit




Do not expose to the sun




Protect from the heat

# HOW TO RECYCLE



# WARRANTY

REGISTER YOUR PRODUCT IN OUR LIMITED WARRANTY WEB PAGE  
OR CONTACT US ABOUT PRODUCT INFORMATION



[stromberg.world/pages/warranty](http://stromberg.world/pages/warranty)

# STROMBERG




TEMPO-2




# WHAT'S IN THE BOX


1




1




1




1



# CONTROL PANEL



STAND BY: Unit will turn off automatically after 10 minutes if it is not in use.



Powerbank

Aux input

Mic input 1

Mic input 2

Mic input 3

DC 15V 2A

On/Off

Volume

Mic +

Mic -

Play/pause

Next

Previous

Lights mode

BT - 3" Disconnect BT

Treble -

Bass -


Bass +

Treble +


Input mode - 3" TWS

# BLUETOOTH CONNECTION

1




2




TO DISCONNECT:

1




2




# STROMBERG CONNECT

WITH OTHER TEMPO-2 MODEL


1




2




3




4



# LET'S PARTY WITH THIS PLAYLIST





BORN IN  
USA  
1894

