



5300PaUltra-PowerfulRobot Vacuum and Mop

Tapo RV20 Max





MagSlim™ + IMU Dual Navigation System

83 mm / 3.27" Ultra-Slim Design Mesh Grid™ No Spots Missed Customizable Room Cleaning 52 dB Quiet Clean[†]








Highlights

DeepVac[™] for Better Dust Removal




Highlights

Tapo IQ+ Smart Cleaning™



Highlights



Highlights

MagSlim[™] + IMU Dual Navigation System
 Accurately maps out your house in minutes, reducing omissions and repeated cleaning, and even works well in the dark.

 5300Pa Powerful Suction
 Sweeps away debris sandwiched between gaps and dust hidden in carpets for a deeper, powerful clean.

83 mm / 3.27" Ultra-Slim Design

Moves freely under furniture to reach hidden dirt and grime that can't escape its sweep.

52 dB Quiet Clean[†]
 Lower noise level to 52 dB - quieter than a running microwave,
 ensuring a hushed cleaning experience.

Up to 180 min Continuous Cleaning[†]
 The high-performance battery provides up to 180 minutes of continuous cleaning to clean your house in one run.

Up to 22 mm / 0.87 in Super Hurdle Capacity
 Effortlessly climbs over thresholds and obstacles under 22 mm / 0.87 in to provide a more thorough cleaning experience.

Voice & Remote Control
 Simply send voice commands via smart speakers or control via the
 Tapo app.

Up to 4 Multi-Floor Cleaning*
 Accurately recognizes different floors faster with local-stored maps
 without the need for manual switch.

*Coming soon. Please keep your robot vacuum firmware up to date.

Specifications

Care and Maintenance

To maintain optimal performance, maintain the robot vacuum according to the following guidelines.

Part	Maintenance Frequency	Replacement Frequency*
Dustbin	Clean/wash as needed	
Filter	Once a week	3-6 months
Main Brush	Every 2 weeks	6-12 months
Main Brush Cover	Every 2 weeks	6-12 months
Side Brush	Once a month	3-6 months
Mop Cloth	After each use	2-3 months
Caster Wheel	Clean as needed	/
Main Wheels	Once a month	/
Sensors	Once a month	/
Charging Contacts	Once a month	/

^{*}Replacement frequency may vary depending on the actual situation. Parts should be replaced if visible wear appears.

Specifications

Mapping & Navigation Features

- · Mapping/Path Planning: MagSlim™ + IMU Dual Navigation
- · High-Precision Map: Yes
- · Obstacle Avoidance: Infrared
- · Barrier-Cross Height: 22 mm/0.87 in
- · Anti-Drop Protection : Yes

Vacuuming Features

- · Max Suction Power: 5300 Pa
- · Suction Level Adjustment: 5 levels
- · Dustbin Capacity: 300 ml
- · Dustbin Detection: Yes
- · HEPA Filter: H11
- · Carpet Boost: Yes
- · Noise: 52dB (Quiet mode), 55 dB (Default/Standard)

Mopping Features

- · Wet Mopping: Yes
- Mopping Type: Electric Water Flow Control
- · Water Level Adjustment: 3 levels
- · Water Tank Capacity: 300 ml

Battery

- · Battery Capacity: 2600 mAh
- · Vacuum Max Battery Life: 180 min per charge (Quiet Mode)
- · Recharge & Resume: Yes

App Features

- · Real-Time Tracking: Yes
- · Multi-Floor Mapping: Yes
- · Scheduled Cleaning: Yes
- · Virtual Walls: Yes
- · No-Go Zones: Yes
- · Zone Cleaning: Yes

Specifications

Physical

· Product Dimensions:

Robot Vacuum: Φ330 × 83 mm (Φ13 × 3.3 in)

· Package Contents:

Robot Vacuum Cleaner ×1 (Includes HEPA Filter x1 and Side Brush x1)


Charging Dock ×1

Mopping Attchament ×1

Power Cord ×1

Cleaning Brush ×1

User Manual



Others

· Wireless Connection:

IEEE 802.11 b/g/n, 2.4 GHz band only;

Bluetooth 4.2 (only for onboarding)

- · Rated Input Voltage: 100-240 VAC, 50/60 Hz
- Max Charging Power Consumption: 10 W (DC20 V 500 mA) / 9.5W (DC19 V 500 mA)
- · Max Working Power Consumption:

Robot Vacuum: 45 W

- · Works with Google Home: Yes
- · Works with Amazon Alexa: Yes



Robot Vacuum



(d) Power/Clean

- Press and hold for 3 seconds: Turn on/off the robot vacuum.
- Press once: Start/pause cleaning.

□ Dock

- Return to the dock to charge.
- Empty the dustbin when docked.

Spot Cleaning/Child Lock

- Press once: Start spot cleaning.
- Press and hold for 5 seconds: Turn on/off the child lock.


(A) + (Ca) Combo Button

- Press and hold simultaneously for 5 seconds: Enter setup mode to configure the network.
- Press and hold simultaneously for 10 seconds: Restore to factory default settings.

△ LED

- Red: Battery level < 20%; Error
- Orange: Battery level between 20% and 80%
- Green: Battery level > 80%

Overview



For support and warranty, please visit: https://www.tapo.com/support

[†]Based on internal testing by Tapo Lab. Actual results are subject to change due to the usage and environmental factors.

[‡]Testing is conducted by Tapo Lab using Tapo RV20 Max compared to Tapo RV20 Mop on rough wood floors. Actual results may vary according to the home environment. Specifications are subject to change without notice. All brands and product names are trademarks or registered trademarks of their respective holders. @2024 TP-Link